




Instruction Manual

Unique Mixproof 3-body



2319-0171

100000711-EN5

2022-10

Original manual

The information herein is correct at the time of issue but may be subject to change without prior notice

| | |
|--|-----------|
| 1. Declarations of conformity | 4 |
| 2. Introduction | 6 |
| 3. Safety | 7 |
| 3.1. Important information | 7 |
| 3.2. Warning signs | 7 |
| 3.3. Safety precautions | 8 |
| 4. Installation | 10 |
| 4.1. Unpacking/intermediate storage | 10 |
| 4.2. Recycling | 13 |
| 4.3. General installation | 14 |
| 4.4. Welding | 16 |
| 5. Operation | 18 |
| 5.1. Operation | 18 |
| 5.2. Recommended cleaning | 18 |
| 5.3. Troubleshooting and repair | 24 |
| 6. Maintenance | 25 |
| 6.1. General maintenance | 25 |
| 6.2. Dismantling of valve | 27 |
| 6.3. Lower plug, replacement of radial seals | 30 |
| 6.4. Upper plug, replacement of axial seal | 36 |
| 6.5. Assembly of valve | 38 |
| 6.6. Dismantling of actuator | 44 |
| 6.7. Assembly of actuator | 46 |
| 7. Technical data | 48 |
| 7.1. Technical data | 48 |
| 8. Parts list and service kits | 51 |
| 8.1. Introduction | 51 |
| 8.2. Actuator | 52 |
| 8.3. Plug setup overview | 54 |
| 8.4. Plug setup 23 | 56 |
| 8.5. Plug setup 25 | 58 |
| 8.6. Plug setup 31 | 60 |
| 8.7. Plug setup 33 | 62 |
| 8.8. Plug setup 37 | 64 |
| 8.9. Plug setup 39 | 68 |
| 8.10. Valve bodies | 72 |
| 8.11. Installation kit B | 74 |
| 8.12. Installation kit C | 76 |
| 8.13. Installation kit G | 78 |
| 8.14. Installation kit H + B | 80 |
| 8.15. Axial installation tool | 82 |
| 8.16. Radial installation tool | 84 |

1 Declarations of conformity

EU Declaration of Conformity

The Designated Company

Alfa Laval Kolding A/S, Albuen 31, DK-6000 Kolding, Denmark, +45 79 32 22 00

Company name, address and phone number

Hereby declare that

Valve

Designation

Unique 3 Body

Type

Serial number from 1181354 to 9999999

Serial number from AAB000000001 to AAB999999999

Serial number from 100700000001 to 100799999999

is in conformity with the following directives with amendments:

- Machinery Directive 2006/42/EC

- The valve is in compliance with the Pressure Equipment Directive 2014/68/EC and was subjected to the following assessment procedure Module A

The person authorised to compile the technical file is the signer of this document.

Global Product Quality Manager

Title

Lars Kruse Andersen

Name

Kolding, Denmark

Place

2022-10-01

Date (YYYY-MM-DD)



Signature

This Declaration of Conformity replaces Declaration of Conformity dated 2019-07-30



1 Declarations of conformity

UK Declaration of Conformity

The Designated Company

Alfa Laval Kolding A/S, Albuen 31, DK-6000 Kolding, Denmark, +45 79 32 22 00

Company name, address and phone number

Hereby declare that

Valve

Designation

Unique 3 Body

Type

Serial number from 1181354 to 9999999

Serial number from AAB000000001 to AAB999999999

Serial number from 100700000001 to 100799999999

is in conformity with the following directives with amendments:

- The Supply of Machinery (Safety) Regulations 2008
- The Pressure Equipment (Safety) Regulations 2016 category 1 and subjected to assessment procedure Module A.

Signed on behalf of: Alfa Laval Kolding A/S

Global Product Quality Manager

Title

Lars Kruse Andersen

Name

Kolding, Denmark

Place

2022-10-01

Date (YYYY-MM-DD)



Signature

DoC Revison_01_102022

UK
CA



2 Introduction

Thank you for purchasing an Alfa Laval product.

This manual has been provided to instruct you in how to operate and service this product correctly and safely. Make sure that you follow all directions and instructions; failure to do so could result in personal injury or equipment damage.

This manual should be considered part of this product and should remain with it at all times for reference. (If you sell it, please be sure to include this manual with it.) Warranty is provided as part of Alfa Laval's commitment to our customers who operate and maintain their equipment as this manual dictates. Failure to do so may result in loss of warranty.

Where defects appear on the product during the warranty period, Alfa Laval will take back the product and correct the problem. Should the equipment be modified or not kept in the manner prescribed within this manual, the warranty will become null and void.

*Unsafe practices and other important information are emphasised in this manual.
Warnings are emphasised by means of special signs.*

3.1 Important information

Important information

Always read the manual before using the valve!

WARNING

Indicates that special procedures must be followed to avoid serious personal injury.

CAUTION

Indicates that special procedures must be followed to avoid damage to the valve.

NOTE

Indicates important information to simplify or clarify procedures.

This Instruction manual is designed to provide the user with the information to perform tasks safely for all phases in the lifetime of the product supplied.

The user shall always read the safety section first. Hereafter the user can skip to the relevant section for the task to be carried out or for the information needed.

This is the complete manual for the supplied product.

Operators

The operators shall read and understand the instruction manual for the supplied product.

Maintenance personnel

The maintenance personnel shall read and understand the instruction manual.

The maintenance personnel or technicians shall be skilled within the field required to carry out the maintenance work safely.

Trainees

Trainees can perform tasks under the supervision of an experienced employee.

People in general

The public shall not have access to the supplied product.

How to contact Alfa Laval

Contact details for all countries are

continually updated on our website.

Please visit www.alfalaval.com to access the information directly.

3.2 Warning signs

General warning:



Caustic agents:



Cutting danger:



TD 449-303

3 Safety

*Unsafe practices and other important information are emphasised in this manual.
Warnings are emphasised by means of special signs.*

3.3 Safety precautions

Installation:

- Always** read the technical data thoroughly (see section 7 Technical data)
- Always** release compressed air after use
- Never** touch the clip assembly or the actuator piston rod if the actuator is supplied with compressed air (see warning label)
- Never** stick your fingers through the valve ports if the actuator is supplied with compressed air



Operation:

- Always** read the technical data thoroughly (see section 7 Technical data)
- Never** touch the clip assembly or the actuator piston rod when the actuator is supplied with compressed air (see warning label)
- Never** pressurise air connections (AC1, AC3) simultaneously as both valve plugs can be lifted (can cause mixing)
- Never** touch the valve or the pipelines when processing hot liquids or when sterilising.
- Never** throttle the leakage outlet
- Never** throttle the CIP outlet, if supplied



- Always** handle lye and acid with great care



Maintenance:

- Always** read the technical data thoroughly (see section 7 Technical data)
- Always** fit the seals correctly
- Always** release compressed air after use
- Always** remove the CIP connections, if supplied, before service.
- Never** service the valve when it is hot
- Never** pressurise the valve/actuator when the valve is serviced
- Never** stick your fingers through the valve ports if the actuator is supplied with compressed air
- Never** touch the clip assembly or the actuator piston rod if the actuator is supplied with compressed air (see warning label)
- Never** service the valve with valve and pipelines under pressure



Transportation:

- Always** ensure that compressed air are released
- Always** ensure that all connections is disconnected before attempting to remove the valve from the installation
- Always** drain liquid from valves before transportation
- Always** used predesigned lifting points if defined
- Always** ensure sufficient fixing of the valve during transportation - if specially designed packaging material is available, it must be used

*Unsafe practices and other important information are emphasised in this manual.
Warnings are emphasised by means of special signs.*

STORAGE

Ideally, as a guide Alfa Laval recommend:

- Store supplied product as supplied in original packaging
 - Port opening should be protected against any ingress
 - Bare steel (not stainless) should be lightly oiled/greased
 - Store in a clean, dry place without direct sunlight or UV light
 - Temperature range -5 to 40°C
 - Relative humidity less than 60%
 - No exposure to corrosive substances (also air contained).
-

4 Installation

The instruction manual is part of the delivery.

Study the instructions carefully.

Fit the warning label supplied on the valve after installation so that it is clearly visible.

4.1 Unpacking/intermediate storage

Step 1

CAUTION!


Alfa Laval cannot be held responsible for incorrect unpacking.

Check the delivery for:

1. Complete valve
2. Delivery note
3. Warning label

Step 2

Remove upper support




Step 3

Lift out the valve.

NOTE!

Please note weight of valve as printed on box.




The instruction manual is part of the delivery.

Study the instructions carefully.

Fit the warning label supplied on the valve after installation so that it is clearly visible.


Step 4

Remove possible packing materials from the valve ports.



Step 5

Inspect the valve for visible transport damage.



4 Installation


The instruction manual is part of the delivery.

Study the instructions carefully.

Fit the warning label supplied on the valve after installation so that it is clearly visible.

Step 6

Avoid damaging the air connections, the leakage outlet, the valve ports and the CIP connections.




Step 7

Disassemble according to illustrations (please also see 6.2 Dismantling of valve).

1. Supply compressed air.
2. Remove upper clamp (64).
3. Release compressed air.
4. Lift out actuator with plugs.

Compressed
air supply




Step 8

While valve body is welded, it is recommended to store the valve safely in the box together with valve parts.

1. Place actuator and valve parts in the box.
2. Add supports.
3. Close, re-tape and store the box.

ADVICE!

Mark the valve body and box with the same number before intermediate storage.



4.2 Recycling

Unpacking

- Packing material consists of wood, plastics, cardboard boxes and in some cases metal straps
- Wood and cardboard boxes can be re-used, recycled or used for energy recovery
- Plastics should be recycled or burnt at a licensed waste incineration plant
- Metal straps should be sent for material recycling.

Maintenance

- During maintenance, oil and wearing parts in the machine are replaced
- All metal parts should be sent for material recycling
- Worn out or defective electronic parts should be sent to a licensed handler for material recycling
- Oil and all non-metal wear parts must be disposed off in accordance with local regulations

Scrapping

- At the end of use, the equipment must be recycled according to the relevant, local regulations. Besides the equipment itself, any hazardous residues from the process liquid must be considered and dealt with in a proper manner. When in doubt, or in the absence of local regulations, please contact your local Alfa Laval sales company

4 Installation

Study the instructions carefully and pay special attention to the warnings!
The valve has ends for welding as standard but can also be supplied with fittings.

4.3 General installation

Step 1



- Always read the technical data thoroughly (see section 7 Technical data).
- Always release compressed air after use.
- Never touch the clip assembly or the actuator piston rod if the actuator is supplied with compressed air (see the warning label)



CAUTION!

- Fit the supplied warning label on the valve so that it is clearly visible.
- Alfa Laval cannot be held responsible for incorrect installation

NOTE!

- Mount valves vertically, or as close to vertical as possible having the leakage outlet turned downwards.

Step 2


Avoid stresses to the valve as this can result in deformation of the sealing area and malfunction of the valve (leakage or faulty indication).

Pay special attention to:

- Vibrations
- Thermal expansion of the tubes (especially at long tube lengths)
- Excessive welding
- Overloading of the pipelines

NOTE!

Please follow Alfa Laval installation guidelines (literature code ESE00040).




Step 3

Fittings


Ensure that the connections are tight.

Remember seal rings!




Study the instructions carefully and pay special attention to the warnings!
The valve has ends for welding as standard but can also be supplied with fittings.

Step 4



A = Air out 1A
B = Air in
C = Air out 3
D = Air out 2




AC1 = Air connection 1 upper seat push
AC2 = Air connection 2 open/close
AC3 = Air connection 3 lower seat push

| Valve Pneumatic Connections | |
|-----------------------------|---------------------|
| ThinkTop Fitting ID | Actuator Fitting ID |
| Out 1A | Air connection 2 |
| Out 2 | Air connection 3 |
| Out 3 | Air connection 1 |

Air connection: R 1/8" (BSP).

Step 5

It is important to connect CIP inlet to the small inlet nozzle to avoid built-up pressure in the cleaning chamber.



Align nozzle edges with recess in sealing element.

4 Installation

Study the instructions carefully and pay special attention to the warnings!

The valve has ends for welding as standard.

Weld carefully/aim at stressless welding to avoid deformation on sealing areas.


Check the valve for smooth operation after welding.

4.4 Welding

Step 1



Never stick your fingers in the operating parts of the valve if the actuator is supplied with compressed air.



Step 2

Dismantle the valve in accordance with the description of dismantling the valve, see 6.2 Dismantling of valve

Step 3



Before welding the valve into the pipe line please note:


1. Maintain the minimum clearances "A" so that the actuator with the internal valve parts can be removed - please see later on in this section!

If there is a risk of foot damage, Alfa Laval recommends leaving a distance of 120 mm (4.7") below the valve (look at the specific built-in conditions).

| Size | ISO | | | | DIN | | | |
|------|-----------------|---------------|---------------|----------------|----------|----------|----------|-----------|
| | DN/ OD 51 | DN/OD 63.5 | DN/OD 76.1 | DN/OD 101.6 | DN 50 | DN 65 | DN 80 | DN 100 |
| A | 265 | 300 | 300 | 360 | 265 | 290 | 270 | 350 |
| B* | 835 | 970 | 980 | 1175 | 835 | 970 | 980 | 1175 |
| C | 73.8 | 86.3 | 96.9 | 123.6 | 76 | 92 | 107 | 126 |

NOTE! If ThinkTop® is mounted, add 180 mm (7,1") to B measure.

(All measures in mm) (1 mm = 0.0394")



Study the instructions carefully and pay special attention to the warnings!

The valve has ends for welding as standard.


Weld carefully/aim at stressless welding to avoid deformation on sealing areas.

Check the valve for smooth operation after welding.

Step 4

WARNING

Make sure to turn the valve body correctly - conical valve seat upwards.



Step 5

Assemble the valve in accordance with section 6.5 Assembly of valve after welding.

Pay special attention to the warnings and clamp torque (see section 6.5 Assembly of valve).


Step 6

Pre-use check:

1. Supply compressed air to air connection 1, 2 and 3 one by one.
2. Operate the valve several times to ensure that it runs smoothly.

Pay special attention to the warnings!

- AC1 = Air connection 1 upper seat push
 AC2 = Air connection 2 open/close
 AC3 = Air connection 3 lower seat push



5 Operation

The valve is tested before delivery.

Study the instructions carefully and pay special attention to the warnings!

Pay attention to possible faults.

The items refer to the parts list and service kits section.

5.1 Operation

Step 1



- **Always** read the technical data thoroughly (see section 7 Technical data).
- **Always** release compressed air after use.
- **Never** touch the clip assembly or the actuator piston rod if the actuator is supplied with compressed air (see the warning label).
- **Never** pressurise air connections (AC1, AC3) simultaneously as both valve plugs can be lifted (can cause mixing).


CAUTION!

Alfa Laval cannot be held responsible for incorrect operation.

Step 2



Never touch the valve or the pipelines when processing hot liquids or when sterilising.



5.2 Recommended cleaning

Step 1



Always handle lye and acid with great care.

Caustic danger!



Always use
rubber gloves!



Always use
protective goggles!

The valve is designed for cleaning in place (CIP).

Study the instructions carefully and pay special attention to the warnings!


NaOH = Caustic soda.

HNO₃ = Nitric acid.

Step 2



Never touch the valve or the pipelines when sterilising.




Step 3



- Never throttle the leakage outlet
- Never throttle the CIP outlet, if supplied.
(Risk of mixing due to overpressure).

A = CIP in
B = CIP out



Step 4

1. Avoid excessive concentration of the cleaning agent
⇒ **Dose gradually!**
2. Adjust the cleaning flow to the process
Milk sterilisation/viscous liquids
⇒ **Increase the cleaning flow!**

5 Operation

The valve is designed for cleaning in place (CIP).

Study the instructions carefully and pay special attention to the warnings!

NaOH = Caustic soda.

HNO₃ = Nitric acid.

Step 5

Recommended cleaning - general

Each mixproof valve shall be properly operated, including seat lifting, during CIP cleaning to assure exposure to product contact surfaces.

Alfa Laval offers the option of cleaning the leakage chamber by utilizing the SpiralClean nozzle during the CIP Cleaning.

The SpiralClean nozzle is accessed through the external inlet located at the Intermediate piece.

The CIP through the SpiralClean nozzle can be controlled by an external valve. Minimum recommended CIP pressure 2 bar (29 psi).

Alfa Laval offers the option of cleaning the OD of the upper and lower valve plug shaft(s) by utilizing the CIP sealing elements.

The CIP of the valve shaft(s) has an external inlet and outlet positioned on the sealing elements. Minimum recommended CIP pressure 2 bar (29 psi).

The CIP through the SpiralClean nozzle can be controlled by an external valve(s).

Alfa Laval recommends that OD cleaning of the valve plug shafts is only performed during CIP of the valve. For example: If only the upper portion of the valve body is cleaned while there is product present in the lower portion of the valve body. OD cleaning should only be performed on the upper plug.

Step 6

Recommended cleaning - specific

The chart below provides reference to cleaning solution agents, temperature and exposure times necessary during circulation to achieve good cleaning results.

All data shown is required for each valve during cleaning. Use clean water, free from chlorides, for mixing with chemical cleaning agents.

| CIP event | Exposure time | Temperature | Agent | Concentration |
|----------------------|-----------------------|-------------------------|---------------------------------|---------------|
| Warm pre-rinse | 3 minutes continuous | 38-43 °C (100 – 110 °F) | None | None |
| Hot alkaline wash | 10 minutes continuous | 71 °C (160 °F) | NaOH (Sodium hydroxide) | 1% |
| Cold post wash | 3 minutes continuous | Cold | None | None |
| Cold acidified rinse | 3 minutes continuous | Cold | EHNO ₃ (Nitric acid) | 0.006% |

The valve is designed for cleaning in place (CIP).

Study the instructions carefully and pay special attention to the warnings!

NaOH = Caustic soda.

HNO₃ = Nitric acid.

Step 7

Valve pneumatic operation during in-place cleaning

Each valve seat shall be lifted during the length of the cleaning cycle.

Seat lift durations shall not exceed 10 seconds.

These pneumatic functions include:

1. Upper valve seat lift (takes place during cleaning of upper valve body)
2. Lower valve seat push (takes place during cleaning of lower valve body)

The following chart presents an overview of these functions together with the recommended time durations at 1.5 bar (21 psi) CIP pressure. It is recommended to do seat lift/push in the middle of each step in the CIP sequence.

| CIP event @ length | Valve function | Valve solenoid no. | Solenoid mode | Actual opening time | Number of lifts/push in each CIP step |
|----------------------------------|------------------|--------------------|---------------|---------------------|---------------------------------------|
| Warm pre-rinse @ 3 minutes | Upper seat lift | 3 | Energized | *0.5 sec | 1 |
| | Lower seat lift | 2 | Energized | *0.5 sec | 1 |
| | SpiralClean vent | - | - | *5 sec | 3 |
| | OD cleaning | - | - | *5 sec | 2 |
| Hot alkaline wash @ 10 minutes | Upper seat lift | 3 | Energized | *0.5 sec | 2 |
| | Lower seat lift | 2 | Energized | *0.5 sec | 2 |
| | SpiralClean vent | - | - | *5 sec | 3 |
| | OD cleaning | - | - | *5 sec | 2 |
| Cold post wash @ 3 minutes | Upper seat lift | 3 | Energized | *0.5 sec | 1 |
| | Lower seat lift | 2 | Energized | *0.5 sec | 1 |
| | SpiralClean vent | - | - | *5 sec | 3 |
| | OD cleaning | - | - | *5 sec | 2 |
| Cold acidified rinse @ 3 minutes | Upper seat lift | 3 | Energized | *0.5 sec | 1 |
| | Lower seat lift | 2 | Energized | *0.5 sec | 1 |
| | SpiralClean vent | - | - | *5 sec | 3 |
| | OD cleaning | - | - | *5 sec | 2 |
| Final rinse @ 3 minutes | Upper seat lift | 3 | Energized | *0.5 sec | 1 |
| | Lower seat lift | 2 | Energized | *0.5 sec | 1 |
| | SpiralClean vent | - | - | *5 sec | 3 |
| | OD cleaning | - | - | *5 sec | 2 |

*Time stated is the actual opening time for the valve. Programmed duration is depended on the access to compressed air and response time from PLC.

Variations caused by compressed air are typically:

- Long compressed air supply hoses.
- Small ID on air supply hoses.
- Limited availability of compressed air.
- Some products may require additional number of seat lifts/pushes.
- Duration of seat lift/push depend on available CIP pressure.

5 Operation

The valve is designed for cleaning in place (CIP).

Study the instructions carefully and pay special attention to the warnings!

NaOH = Caustic soda.

HNO₃ = Nitric acid.

Step 8

Consumption cleaning fluids

The table below approximates the flow of cleaning solution through the valve vent tube during seat lift functions, SpiralClean of vent and CIP of OD valve plug shafts at a CIP pressure of 1.5 bar (21 psi).

| Valve size DN/OD / DN | Seat lift seat push | K _v (m ³ /h) | Litre pr. min. (1.5 bar/ 21psi) | Duration | Activations during each CIP event |
|--|------------------------|------------------------------------|------------------------------------|----------|--------------------------------------|
| 51/DN50 | Seat lift | 1.8 | 2.69 | 0.5 sec | 3 |
| | Seat push | 1.3 | 1.83 | | |
| 63.-76.1 / DN65-80 | Seat lift | 2.4 | 3.38 | 0.5 sec | 3 |
| | Seat push | 2.1 | 2.95 | | |
| 101.6 / DN100 | Seat lift | 3.4 | 4.76 | 0.5 sec | 3 |
| | Seat push | 2.6 | 3.67 | | |
| SpiralClean 51-101.6 / DN50-100 | - | 0.14 | 0.16 | 0.5 sec | 3 |
| CIP OD valve plug 51-63.5 / DN50-65 | - | 0.29 | 0.32 | 5 sec | 2 |
| CIP OD valve plug 76.1-101.6 / DN80-100 | - | 0.34 | 0.40 | 5 sec | 2 |

Formula to estimate CIP flow during seat lift (for liquids with comparable viscosity and density to water)

$$Q = K_v \cdot \sqrt{\Delta p}$$

Q = CIP - flow (m³/h).

K_v value from the table above.

Δp = CIP pressure (bar).

Assumption: density = 1

Step 9

Guide rings cleaning


When the valves are removed for replacement of wetted parts and / or sealing elastomers, it is important to remove, and hand clean, the PTFE guide rings (positions 45, 54, 80 and 98) and their seating groves before placing the valves back into service. See section 6.5 Assembly of valve

Step 10

Always rinse well with clean water after cleaning.

NOTE!

The cleaning agents must be stored/disposed of in accordance with current regulations/directives.




The valve is designed for cleaning in place (CIP).
Study the instructions carefully and pay special attention to the warnings!
NaOH = Caustic soda.
HNO₃ = Nitric acid.


Step 11

Seat-cleaning cycles:
 Pay special attention to the warnings!


1. Closed valve




2. Open valve



3. Cleaning through upper line



4. Cleaning through lower line



5 Operation

Study the maintenance instructions carefully before replacing worn parts. - See section 6.1 General maintenance

5.3 Troubleshooting and repair

| Problem | Cause/result | Repair |
|---|---|---|
| Leakage between sealing element (79 or 96/97) and lower plug (75) | Worn/product affected o-rings/ lip seal (76/77/78/95) | <ul style="list-style-type: none">- Replace the o-rings/lip seal- Change rubber grade- Lubricate correctly |
| Leakage at the leakage outlet | <ul style="list-style-type: none">- Particles between valve seats and plug seals (56/74)- Worn/product affected plug seal rings (56/74)- Plug not assembled correctly | <ul style="list-style-type: none">- Remove the particles- Check the plug seals- Replace the plug seals- Change rubber grade- Assemble plug, see section 6.3 Lower plug, replacement of radial seals and section 6.4 Upper plug, replacement of axial seal |
| Leakage at sealing element (48)/upper plug (55) | Worn/product affected o-rings/lip seal (38/39/46/49) | <ul style="list-style-type: none">- Replace the o-rings/lip seal- Change rubber grade- Clean and if necessary replace guide ring (45) |
| Leakage at clamp (64) | <ul style="list-style-type: none">- Too old/product affected o-rings (76 and 47) (and 52 if clamped valve body)- Loose clamp (64) | <ul style="list-style-type: none">- Replace the o-rings- Change rubber grade- Tighten the clamp |
| CIP leakage | Worn o-rings (40/67/71/144/145) | Replace the o-rings |
| Leakage at spindle clamp (43) | Damaged o-ring (39) Worn/product affected lip seal (57) or spray nozzle (58) | <ul style="list-style-type: none">- Replace the o-ring- Replace the plug seals- Change rubber grade |
| Lower plug not returning to closed position | <ul style="list-style-type: none">- Wrong rubber grade- Wrongly fitted gasket- Mounted incorrectly (see section 6.3 Lower plug, replacement of radial seals) | <ul style="list-style-type: none">- Change rubber grade- Fit new gasket correctly- Correct installation |
| Plug returns with uneven movements (slip/stick effect) | <ul style="list-style-type: none">- Wrong rubber grade- Wrongly fitted gasket- Mounted incorrectly (see section 6.3 Lower plug, replacement of radial seals) | <ul style="list-style-type: none">- Change rubber grade- Fit new gasket correctly- Correct installation |

The valve is designed so that internal leakages do not result in the products becoming mixed.

Internal leakage in the valve is externally visible.

Study the instructions carefully.

Always keep spare rubber seals and guide rings in stock. Check the valve for smooth operation after service.

6.1 General maintenance

Recommended spare parts: service kits (see 8 Parts list and service kits)

Order service kits from the service kits section, see 8 Parts list and service kits

Ordering spare parts: contact the sales department.

| | Valve rubber seals | Valve plug seals | Valve guide rings |
|---|---|---|-----------------------|
| Preventive maintenance | Replace after 12 months (*) | Replace after 12 months (*) | Replace when required |
| Maintenance after leakage (leakage normally starts slowly) | Replace after production cycle | Replace after production cycle | Replace when required |
| Planned maintenance | <ul style="list-style-type: none"> - regular inspection for leakage and smooth operation - Keep a record of the valve - Use the statistics for planning of inspections | <ul style="list-style-type: none"> - Regular inspection for leakage and smooth operation - Keep a record of the valve - Use the statistics for planning of inspections | |
| Lubrication | When assembling Alfa Laval Silicon based Food-grade Lubricant USDA H1 approved grease | When assembling Alfa Laval Silicon based Food-grade Lubricant USDA H1 approved grease | None |

Note!

Lubricate thread in valve plug parts with Alfa Laval Lubricant or similar.

(*) Depending on working conditions! Please contact Alfa Laval.

(**) All product wetted seals.

Repairing of actuator

- The actuator is maintenance-free, but repairable.
- If repair is required, replacing all actuator rubber seals is recommended.
- Lubricate seals with Alfa Laval Lubricant.
- To avoid possible black remains on position number 1 and 29. Alfa Laval recommends Alfa Laval Lubricant for these two positions.

6 Maintenance

The valve is designed so that internal leakages do not result in the products becoming mixed.

Internal leakage in the valve is externally visible.


Study the instructions carefully.

Always keep spare rubber seals and guide rings in stock. Check the valve for smooth operation after service.

Pre-use check

1. Supply compressed air to AC1, AC2 and AC3 one by one
2. Operate the valve several times to ensure that it operates smoothly.

Pay special attention to the warnings!



The valve is designed so that internal leakages do not result in the products becoming mixed.

Internal leakage in the valve is externally visible.

Study the instructions carefully.

Always keep spare rubber seals and guide rings in stock. Check the valve for smooth operation after service.

6.2 Dismantling of valve


Step 1

Disassemble valve acc. to illustrations (1 to 6)

1. Supply compressed air to AC2.
2. Loosen and remove upper clamp (64).
3. Release compressed air.
4. Lift out the actuator together with the internal valve parts from valve body (50).
5. Loosen and remove middle clamp (64) and remove valve body (149) and o-ring (148) from valve body (149).
6. Loosen and remove lower clamp (64).
7. Take away lower sealing element (A, B or C).

Note!

Release compressed air.



A

Dismantling of lower sealing element

1. Pull out o-ring (76) and lip seal (77).
2. Remove guide ring (80).

B

Dismantling of lower sealing element, balanced with CIP
OD balancer

1. Pull out o-ring (76) and lip seal (77).
2. Remove o-ring (78).
3. Remove guide ring (80).
4. Screw out flushing tubes (70).
5. Remove o-rings (71).
6. Remove nozzles (72 + 73).

C

Dismantling of lower sealing element, flush OD balancer

1. Remove upper part of sealing element (96)
2. Pull out o-ring (76) and lip seal (95).
3. Remove guide ring (98) from lower part of sealing element (97).

6 Maintenance

The valve is designed so that internal leakages do not result in the products becoming mixed.

Internal leakage in the valve is externally visible.

Study the instructions carefully.


Always keep spare rubber seals and guide rings in stock. Check the valve for smooth operation after service.

Step 2

1. Supply compressed air for air connection AC1.
2. Loosen lower plug (146 + 147) while counterholding upper stem (1).
3. Remove the plug.
4. Release compressed air.

Note: For replacement of seal ring (74), please see section 6.3
Lower plug, replacement of radial seals.

1 = on
4 = off



2319-0163

The valve is designed so that internal leakages do not result in the products becoming mixed.

Internal leakage in the valve is externally visible.

Study the instructions carefully.

Always keep spare rubber seals and guide rings in stock. Check the valve for smooth operation after service.

Step 3

Remove coupling system and upper plug according to illustrations (1-4)

1. No SpiralClean in leakage chamber :

A. Unscrew plug (15)

SpiralClean in leakage chamber :

A. Unscrew flushing tube (41).


B. Remove o-ring (40)

2. Pull up lock (44) over piston rod (29)

3. Pull away clamps (43) from spindle liner (42)

4. Pull out upper plug (55). Make sure spindle liner (42) is free of both piston rod and upper plug.

SpiralClean in leakage chamber: Remove both o-rings (39) on valve plug (55) and piston rod (29)



Step 4


A

Dismantling of upper sealing element

1. Remove sealing element (48) from intermediate piece (37).

2. Pull out o-ring (47) and lip seal (49) from sealing element (48)

3. Remove guide ring (45).



6 Maintenance

The valve is designed so that internal leakages do not result in the products becoming mixed.


Internal leakage in the valve is externally visible.

Study the instructions carefully.

Always keep spare rubber seals and guide rings in stock. Check the valve for smooth operation after service.

Step 5

Remove lip seal (57) and guide ring (54) (or spray nozzle (58) if valve is supplied with SpiralClean in leakage chamber. For removal and replacement of seal ring (56), please see section 6.4 Upper plug, replacement of axial seal




6.3 Lower plug, replacement of radial seals

Step 1

Cut and remove old seal ring (74), where indicated, using a knife, screwdriver or similar.

Be careful not to scratch the plug.



The valve is designed so that internal leakages do not result in the products becoming mixed.

Internal leakage in the valve is externally visible.

Study the instructions carefully.


Always keep spare rubber seals and guide rings in stock. Check the valve for smooth operation after service.

Step 2

Pre-mount seal ring as shown on drawing.


Rotate along circumference to fix sealing as shown in the picture.


Carefully lubricate sealings with suitable soap or lubricant (Alfa Laval Lubricant), before pre-mounting.



Step 3

Place lower tool part.




| Item no. | Item no. | Item no. | |
|------------|------------|------------|--|
| Seat ø53 | Seat ø81 | Seat ø100 | Tool for radial sealing, lower plug |
| 9613426001 | 9316426002 | 9613426003 |  |

Step 4

1. Place upper tool part including piston.

2. Clamp the two tool parts together.



6 Maintenance

The valve is designed so that internal leakages do not result in the products becoming mixed.


Internal leakage in the valve is externally visible.

Study the instructions carefully.

Always keep spare rubber seals and guide rings in stock. Check the valve for smooth operation after service.


Step 5

1. Supply compressed air.
2. Release compressed air.
3. Remove tool parts.



Step 6

Inspect the seal to ensure it does not twist in the groove, and press in the 4 outsticking points with a screwdriver



The valve is designed so that internal leakages do not result in the products becoming mixed.


Internal leakage in the valve is externally visible.

Study the instructions carefully.

Always keep spare rubber seals and guide rings in stock. Check the valve for smooth operation after service.

Step 7

Unscrew the lower piece of the plug (147) from the top piece (146) with a hook spanner at the bottom.



6 Maintenance

The valve is designed so that internal leakages do not result in the products becoming mixed.

Internal leakage in the valve is externally visible.

Study the instructions carefully.

Always keep spare rubber seals and guide rings in stock. Check the valve for smooth operation after service.


Step 8

Remove the seal ring (74) that is placed between the two pieces and the O-ring (151) on the upper plug part.

Before pre-mounting the new seal ring and O-ring remember to lubricate with suitable soap or lubricant (Klüber Paraliq GT 703).

Fit O-ring (151) in the upper plug part (146).

Now pre-mount the new seal ring in the groove on the upper plug part (146).



The valve is designed so that internal leakages do not result in the products becoming mixed.

Internal leakage in the valve is externally visible.

Study the instructions carefully.


Always keep spare rubber seals and guide rings in stock. Check the valve for smooth operation after service.

Step 9

Reassemble the two plug pieces with the hook spanner.

Be careful to ensure a nice fit of the seal ring when tightening the two parts.

(Maximum torque for hook spanner 20 Nm/ 14.8 lbf-ft)



6 Maintenance

The valve is designed so that internal leakages do not result in the products becoming mixed.

Internal leakage in the valve is externally visible.


Study the instructions carefully.

Always keep spare rubber seals and guide rings in stock. Check the valve for smooth operation after service.

6.4 Upper plug, replacement of axial seal


Step 1

Remove old seal ring (56) using a knife, screwdriver or similar. Be careful not to scratch the plug.



Step 2

Pre-mount seal ring as shown on drawing.



Carefully lubricate sealings with suitable soap or lubricant (Alfa Laval Lubricant), before pre-mounting.


The valve is designed so that internal leakages do not result in the products becoming mixed.

Internal leakage in the valve is externally visible.

Study the instructions carefully.


Always keep spare rubber seals and guide rings in stock. Check the valve for smooth operation after service.

Step 3

| Item no. | Item no. | Item no. | |
|------------|------------|------------|--|
| Seat ø53 | Seat ø81 | Seat ø100 | Tool for axial sealing, upper plug |
| 9613050501 | 9613050502 | 9613050508 |  |

Step 4


Place tool part 1.



Step 5


1. Place tool part 2 including piston.
2. Clamp the two tool parts together.

Tooling marked with item number




Step 6

1. Supply compressed air.
2. Release compressed air.
3. Rotate the tool 45° in relation to the plug.
4. Supply compressed air.
5. Release compressed air and remove tool.



Step 7

1. Inspect the seal.
2. Release air at 3 different positions of the circumference.



6 Maintenance

The valve is designed so that internal leakages do not result in the products becoming mixed.

Internal leakage in the valve is externally visible.

Study the instructions carefully.

Always keep spare rubber seals and guide rings in stock. Check the valve for smooth operation after service.

6.5 Assembly of valve

Step 1


A

Assembly of upper sealing element

1. Fit o-ring (47) (do not twist), and lip seal (49) in upper sealing element (48) (Lubricate with Alfa Laval Lubricant).

NOTE: The o-ring should be gently pressed into the groove.

2. Fit guide ring (45) in upper sealing element.
3. Fit upper sealing element in intermediate piece (37).



C = Lubricate with Alfa Laval Lubricant on ID

Step 2


1. Place guide ring (54) and lip seal (57) in upper plug or nozzle (58) by SpiralClean in leakage chamber.
2. Mount o-ring (38) in lower plug.
3. Press lower plug (146 + 147) rapidly into upper plug (55) through the lip seal.

Note: Do not damage the lips when lower plug (146 + 147) with o-ring (38) passes the lip seal.


Note:

For Valve Sizes DN/OD 38 & DN40 & DN/OD51 & DN50:

Lip seal (57) can optionally be mounted with special tool, please contact Alfa Laval.



Mounting tool for lip seal item # 8010017878



The valve is designed so that internal leakages do not result in the products becoming mixed.

Internal leakage in the valve is externally visible.


Study the instructions carefully.

Always keep spare rubber seals and guide rings in stock. Check the valve for smooth operation after service.

Step 3

Place coupling system and upper plug according to illustrations.

1. Push lock (44) up over piston rod (29).
2. If SpiralClean in leakage chamber: place o-rings (39) in groove on upper plug (55) and piston rod (29).
3. Place spindle liner (42) on piston rod (29). Fit upper plug (55).
4. Mount clamps (43) on spindle liner (42).
5. Fit lock (44).
6. Fit plug (15) or flushing tube (41) and o-ring (40) if SpiralClean in leakage chamber.



6 Maintenance

The valve is designed so that internal leakages do not result in the products becoming mixed.


Internal leakage in the valve is externally visible.

Study the instructions carefully.

Always keep spare rubber seals and guide rings in stock. Check the valve for smooth operation after service.

Step 4

1. Supply compressed air for air connection AC1
2. Insert lower plug (146 + 147) and tighten
3. Release compressed air



2319-0189

The valve is designed so that internal leakages do not result in the products becoming mixed.


Internal leakage in the valve is externally visible.

Study the instructions carefully.

Always keep spare rubber seals and guide rings in stock. Check the valve for smooth operation after service.

Step 5

1. Fit o-ring (148) (do not twist the o-ring) and press it gently into the groove in valve body (149) (Alfa Laval Lubricant)
2. Fit and tighten middle clamp (64) on valve body (149) Lubricating of clamp and clamp nut recommended! (Maximum torque for clamp nut: 10Nm/7.4 lbf-ft)



D = Lubricate with Alfa Laval Lubricant

A - Assembly of lower sealing element

1. Fit lip seal (77) and o-ring (76) (do not twist the o-ring) and press it gently into the groove (lubricate with Alfa Laval Lubricant)
2. Fit guide ring (80) into sealing element (79)

B - Assembly of lower sealing element with CIP OD balancer

1. Fit o-ring (76) (do not twist), lip seal (77) and o-ring (78) in lower sealing element (lubricate with Alfa Laval Lubricant).
Note! The o-ring (76) should be gently pressed into the groove.
2. Fit guide ring (80) in lower sealing element.
3. Place o-rings (71) and mount flushing tubes (70). Be sure to align nozzles (72 + 73) towards recess.

C - Assembly lower sealing element with flush OD balancer

1. Fit o-ring (76) (do not twist the o-ring) in upper part of sealing element (lubricate with Alfa Laval Lubricant).
Note! The o-ring should be gently pressed into the groove.
2. Place guide ring (98) in lower part of sealing element (97).
3. Fit lip seal (95) in sealing element (97).
4. Place upper part of sealing element (96) on top of lower part of sealing element (97).

6 Maintenance

The valve is designed so that internal leakages do not result in the products becoming mixed.

Internal leakage in the valve is externally visible.

Study the instructions carefully.

Always keep spare rubber seals and guide rings in stock. Check the valve for smooth operation after service.


Step 6

- **Never** stick your fingers through the valve ports if the actuator is supplied with compressed air.
- **Always** supply compressed air, before demounting the valve.

1. Fit lower sealing element (A, B or C)
2. Fit and tighten lower clamp (64)
3. Supply compressed air and mount the actuator together with the internal valve parts from valve body (50)
4. Fit and tighten upper clamp (64). Lubricating of clamp and clamp nut recommended!
(Maximum torque for clamp nut: 10Nm/7.4 lbf-ft)
5. Release compressed air.

Note!

Supply compressed air before mounting the valve.



6 Maintenance


The valve is designed so that internal leakages do not result in the products becoming mixed.

Internal leakage in the valve is externally visible.

Study the instructions carefully.

Always keep spare rubber seals and guide rings in stock. Check the valve for smooth operation after service.

6.6 Dismantling of actuator



The valve is designed so that internal leakages do not result in the products becoming mixed.

Internal leakage in the valve is externally visible.

Study the instructions carefully.

Always keep spare rubber seals and guide rings in stock. Check the valve for smooth operation after service.

Step 1

1. Dismantle the valve in accordance with instructions in section 6.1 General maintenance

Pay special attention to the warnings!

2. The actuator is now ready for service. Please see drawing when dismantling according to steps 2 to 6 on this page.

Note! The actuator is maintenance free but repairable.

Step 2

1. Remove nuts (36) and washers (35).
 2. Pull out intermediate piece (37) from the actuator.
 3. Remove cover disk (25).
 4. Remove retaining ring (24).
-

Step 3

1. Remove piston rod (29), bottom (21) and lower piston (30).
 2. Separate the three parts.
 3. Remove o-rings (20, 22 and 23) from bottom, o-rings (33 and 31) and guide ring (32) from lower piston as well as o-ring (28) from piston rod.
 4. Remove spring assembly (14).
-

Step 4

1. Remove inner stem (27), main piston (17) and distance spacer and screw (11/11.1) (only size 51mm/DN50).
Remove guide ring (18) and o-ring (19)
 2. Remove spring assembly (10).
-

Step 5

Note! Not on actuator size 51mm/DN50

1. Unscrew screws (2) (are glued!).
 2. Remove stop (4).
 3. Remove upper piston (8). Remove o-rings (7 and 9).
-

Step 6

1. Remove o-ring (5) and guide ring (6).
-

6 Maintenance


The valve is designed so that internal leakages do not result in the products becoming mixed.

Internal leakage in the valve is externally visible.

Study the instructions carefully.

Always keep spare rubber seals and guide rings in stock. Check the valve for smooth operation after service.

6.7 Assembly of actuator



The valve is designed so that internal leakages do not result in the products becoming mixed.

Internal leakage in the valve is externally visible.

Study the instructions carefully.

Always keep spare rubber seals and guide rings in stock. Check the valve for smooth operation after service.

Step 1

Please see drawing when reassembling according to steps 2 to 6 on this page.

Note! The actuator is maintenance free but repairable.

Step 2

1. Fit guide ring (6) and o-ring (5).
-

Step 3

Note! Not on actuator size 51mm/DN50

1. Fit o-rings (7 and 9). Place upper piston (8).
 2. Fit stop (4).
 3. Tighten screws (2). (Secure with glue)
-

Step 4

1. Place spring assembly (10).
 2. Fit o-ring (19) and guide ring (18). Mount distance spacer (11) and screw (11.1) (only for size 51mm/DN50), main piston (17) and inner stem (27).
-

Step 5

1. Fit spring assembly (14).
 2. Fit o-ring (28) in piston rod, fit o-rings (33 and 31) and guide ring (32) in lower piston and fit o-rings (20, 22 and 23) in bottom.
 3. Fit piston rod (29), lower piston (30) and bottom (21).
 4. Mount the three parts.
-

Step 6

1. Fit retaining ring (24).
 2. Fit cover disk (25).
 3. Mount intermediate piece (37) on actuator.
 4. Fit and tighten nuts (36) and washers (35).
-

7 Technical data

7.1 Technical data

| Data | |
|---|---|
| Max. product pressure | 1000 kPa (10 bar) (145 psi) |
| Min. product pressure | Full vacuum |
| Recommended min. pressure for SpiralClean | 2 bar (29 psi) |
| Temperature range | -5°C to +125°C (23°F - 257°F) (depending on rubber quality) |
| Air pressure | Max. 800 kPa (8 bar) (116 psi) |
| Materials | |
| Product wetted steel parts | Acid-resistant steel AISI 316L |
| Other steel parts | Stainless steel AISI 304 |
| Product wetted parts | EPDM, HNBR, NBR or FPM |
| Other seals | CIP seals: EPDM |
| Actuator seals | NBR |
| Surface finish | Internal/external matt (blasted) Ra < 1.6 (64 μ") Internal bright (polished) Ra < 0.8 (32 μ") Internal/external bright (internal polished) Ra < 0.8 (32 μ") |

Note!

The Ra-values are only for the internal surface.

Recommended minimum pressure for SpiralClean: 2 bar/flow rate 1.15 m³/h.

Formula to estimate CIP flow during seat lift (for liquids with comparable viscosity and density to water)

$$Q = K_v \cdot \sqrt{\Delta p}$$

Q = CIP - flow (m³/h)

Kv = Kv value from the below table

Δp = CIP pressure (bar)

Assumption: density = 1

Cv = 1.163 x Kv gpm

1 bar = 14.5 psi

| Size | DN/OD | | | | DN | | | |
|--|-------|------|------|-------|------|------|------|------|
| | 51 | 63.5 | 76.1 | 101.6 | 50 | 65 | 80 | 100 |
| Kv-value - upper seat-lift [m³/h] | 1.8 | 2.4 | 2.4 | 3.4 | 1.8 | 2.4 | 2.4 | 3.4 |
| Kv-value - lower seat-lift [m³/h] | 1.3 | 2.1 | 2.1 | 2.6 | 1.3 | 2.1 | 2.1 | 2.6 |
| Air consumption - upper seat-lift *[n litre] | 0.2 | 0.4 | 0.4 | 0.62 | 0.2 | 0.4 | 0.4 | 0.62 |
| Air consumption - lower seat-lift *[n litre] | 1.1 | 0.13 | 0.13 | 0.21 | 1.1 | 0.13 | 0.13 | 0.21 |
| Air consumption - main movement *[n litre] | 0.86 | 1.63 | 1.63 | 2.79 | 0.86 | 1.63 | 1.63 | 2.79 |

For further information concerning cleaning of the valve, please see section 5.2 Recommended cleaning, step 5, 6, 7 & 8.

Noise

1.6 m (5 1/4 Ft) above the exhaust the noise level of a valve actuator will be approximately 77db(A) without noise damper and approximately 72 db(A) with damper - Measured at 7.6 bar (102 psi) air-pressure.

Safety check

A visual inspection of any protective device (shield, guard, cover or other) on the supplied product shall be carried out at least every 12 months.

If the protective device is lost or damaged, especially when this leads to deterioration of safety performance, it shall be replaced. The fixing of the protective device should only be replaced with fixings of the same or an equivalent type.

Inspection acceptance criteria:

- It should not be possible to reach moving parts originally protected by a protective device.
- The protective device must be securely mounted.
- Ensure that screws for the protective device are securely tightened.

Procedure in case of non-acceptance:

- Fix and/or replace the protective device.
-

For spare parts please refer to spare parts catalogue.

8.1 Introduction


Due to the modular design of the Unique Mixproof valve this spare part document is divided into 4 main categories: actuator, plug setup (product wetted parts), valve bodies, and installation tools.

1. **Actuator**, covers the spare parts for all size actuators with an exploded view of the actuator and detailed spare part listing. Service kits are available for the actuator wear parts and the components included in the kits are denoted with a circle around the position number on the exploded view. A table for completed actuators by size and function is also shown for replacement or spare actuators
 2. **Plug setup**, is broken into two sections: plug setup overview and product wetted parts. The plug setup overview enables the customer to easily find the plug setup of the purchased valve and lists the page number of the components for the given plug setup. All of the product wetted parts are shown in an exploded view and listed by valve size. Mixed sized valves are not included in the plug setup section. For more information on the mixed valves please use configurator in Alfa Laval Anytime or contact your local Authorized Alfa Laval Distributor. Service kits for wear parts are available per size for all types of valves including mixed sized valves and the components in the kit are denoted with a circle around the position number in the exploded view.
 3. **Valve bodies**, lists the part numbers for replacement housings. Mixed sized housings are not included in the valve bodies section. For more information on the mixed housings please use configurator in Alfa Laval Anytime or contact your local Authorized Alfa Laval Distributor. You will also find the intermediate pieces in this section.
 4. **Installation tools**, lists the part numbers for the seat installation tools. These tools enable the customer to install the plug seat seals in an efficient and effortless manner by use of compressed air. For more information regarding the use of the tools please refer to the instruction manual or contact your local Authorized Alfa Laval Distributor.
-

8 Parts list and service kits

For spare parts please refer to spare parts catalogue.

8.2 Actuator



- = actuator service kit
* = not used in actuator 2"
** = not used in actuator 2½", 3" and 4"

8 Parts list and service kits

For spare parts please refer to spare parts catalogue.

Parts list


| Pos. | Qty | Denomination |
|------|-----|-----------------------|
| □ | | Actuator service kits |
| 1 | 1 | Upper stem |
| 2 | 4 | Screw |
| 3 | 1 | Air fitting |
| 3.1 | 1 | Air fitting |
| 3.2 | 1 | Air fitting |
| 4 | 1 | Stop for upper piston |
| 5 | 1 | O-ring, NBR |
| 6 | 1 | Guide ring, Turcite |
| 7 | 1 | O-ring, NBR |
| 8 | 1 | Upper piston |
| 9 | 1 | O-ring, NBR |
| 10 | 1 | Spring assembly |
| 11 | 1 | Distance spacer |
| 12 | 1 | Pin |
| 13 | 1 | Washer |
| 14 | 1 | Spring assembly |
| 15 | 1 | Plug |
| 15.1 | 1 | Plug |
| 17 | 1 | Main piston |
| 18 | 1 | Guide ring, Turcite |
| 19 | 1 | O-ring, NBR |
| 20 | 1 | O-ring, NBR |
| 21 | 1 | Bottom |
| 22 | 1 | Guide ring, Turcite |
| 23 | 1 | O-ring, NBR |
| 24 | 1 | Retaining ring |
| 25 | 1 | Cover disk |
| 26 | 1 | O-ring, NBR |
| 27 | 1 | Inner stem |
| 28 | 1 | O-ring |
| 29 | 1 | Piston rod |
| 30 | 1 | Lower piston |
| 31 | 1 | O-ring, NBR |
| 32 | 1 | Guide ring, Turcite |
| 33 | 1 | O-ring, NBR |
| 34 | 3 | Bolt |
| 35 | 3 | Washer |
| 36 | 3 | Nut |
| 41 | 1 | Flushing tube |
| 42 | 1 | Spindle liner |
| 43 | 2 | Clamp |
| 44 | 1 | Lock |

8 Parts list and service kits

For spare parts please refer to spare parts catalogue.


8.3 Plug setup overview

Plug setup 23




Upper: Unbalanced with CIP OD spindle
Lower: Balanced (blue bottom)
See page 56

Plug setup 25




Upper: Unbalanced with CIP OD spindle
Lower: Balanced with CIP OD balancer (blue bottom)
See page 58

Plug setup 31



Upper: Unbalanced
Lower: Balanced (blue bottom)
See page 60

Plug setup 33




Upper: Unbalanced
Lower: Balanced with CIP OD balancer (blue bottom)
See page 62

8 Parts list and service kits


For spare parts please refer to spare parts catalogue.

Plug setup 37



Upper: Unbalanced with CIP OD spindle
Lower: Flush OD Balancer (steel bottom)
See page 64

Plug setup 39




Upper: Unbalanced
Lower: Flush OD Balancer (steel bottom)
See page 68

8 Parts list and service kits


For spare parts please refer to spare parts catalogue.

8.4 Plug setup 23



○ = wear parts

Pos. 37, see section 8.10 Valve bodies
See note below service kits.



2319-0201

8 Parts list and service kits

For spare parts please refer to spare parts catalogue.

Parts list

| Pos. | Qty | Denomination |
|------------------------------|-----|---------------------------------------|
| 15 | 1 | Plug |
| 38 <input type="checkbox"/> | 1 | O-ring |
| 39 | 2 | O-ring |
| 40 | 1 | O-ring |
| 41 | 1 | Flushing tube |
| 42 | 1 | Spindle liner |
| 43 | 2 | Clamp |
| 44 | 1 | Lock |
| 45 | 1 | Guide ring |
| 46 <input type="checkbox"/> | 1 | O-ring |
| 47 <input type="checkbox"/> | 1 | O-ring |
| 48 | 1 | Upper sealing element |
| 49 <input type="checkbox"/> | 1 | Lip seal |
| 54 | 1 | Guide ring |
| 55 | 1 | Upper plug |
| 56 <input type="checkbox"/> | 1 | Seal ring |
| 57 <input type="checkbox"/> | 1 | Lip seal, EPDM |
| 58 | 1 | Spray nozzle |
| 66 | 2 | Flushing tube |
| 67 <input type="checkbox"/> | 2 | O-ring |
| 68 | 1 | Drain |
| 69 | 1 | Nozzle |
| 74 <input type="checkbox"/> | 2 | Seal ring |
| 76 <input type="checkbox"/> | 1 | O-ring |
| 77 <input type="checkbox"/> | 1 | Lip seal |
| 79 | 1 | Lower sealing element |
| 80 | 1 | Guide ring, PTFE |
| 81 | 1 | Cover |
| 146 | 1 | Lower plug, upper part |
| 147 | 1 | Balancer |
| 148 <input type="checkbox"/> | 1 | O-ring |
| 150 | 1 | Lower plug, complete (Pos. 146 + 147) |
| 151 <input type="checkbox"/> | 1 | O-ring |

Service kits

| | | DN/OD 51 | DN/OD 63.5 | | | DN/OD 101.6 |
|--------------------------|-------------------------|------------|------------|------------|------------|-------------|
| | | DN 50 | DN 65 | DN/OD 76.1 | DN 80 | DN 100 |
| Denomination | | seat ø53.3 | seat ø81.3 | seat ø81.3 | seat ø81.3 | seat ø100.3 |
| <hr/> | | | | | | |
| Service kits | | | | | | |
| <input type="checkbox"/> | Service kit, EPDM | 9611928381 | 9611928382 | 9611928382 | 9611928382 | 9611928383 |
| <input type="checkbox"/> | Service kit, NBR | 9611928384 | 9611928385 | 9611928385 | 9611928385 | 9611928386 |
| <input type="checkbox"/> | Service kit, FPM | 9611928387 | 9611928388 | 9611928388 | 9611928388 | 9611928389 |
| <input type="checkbox"/> | Service kit, HNBR | 9611928390 | 9611928391 | 9611928391 | 9611928391 | 9611928392 |

Parts marked with ☐ are included in the service kit.

NOTE!


If SpiralClean in leakage chamber extra O-rings (2 x pos. 39 and 1 x pos. 40) is required.

All FPM service kits are supplied with EPDM seal ring, pos. 74.

8 Parts list and service kits

For spare parts please refer to spare parts catalogue.

8.5 Plug setup 25



8 Parts list and service kits

For spare parts please refer to spare parts catalogue.

Parts list

| Pos. | Qty | Denomination |
|-------|-----|---------------------------------------|
| 15 | 1 | Plug |
| 38 □ | 1 | O-ring |
| 39 | 2 | O-ring |
| 40 | 1 | O-ring |
| 41 | 1 | Flushing tube |
| 42 | 1 | Spindle liner |
| 43 | 2 | Clamp |
| 44 | 1 | Lock |
| 45 | 1 | Guide ring |
| 46 □ | 1 | O-ring |
| 47 □ | 1 | O-ring |
| 48 | 1 | Upper sealing element |
| 49 □ | 1 | Lip seal |
| 54 | 1 | Guide ring |
| 55 | 1 | Upper plug |
| 56 □ | 1 | Seal ring |
| 57 □ | 1 | Lip seal |
| 58 | 1 | Spray nozzle, PVDF |
| 66 | 2 | Flushing tube |
| 67 □ | 2 | O-ring |
| 68 | 1 | Drain |
| 69 | 1 | Nozzle |
| 70 | 2 | Flushing tube |
| 71 □ | 2 | O-ring |
| 72 | 1 | Drain |
| 73 | 1 | Nozzle |
| 74 | 2 | Seal ring |
| 76 □ | 1 | O-ring |
| 77 □ | 1 | Lip seal |
| 78 □ | 1 | O-ring |
| 79 | 1 | Lower sealing element |
| 80 | 1 | Guide ring |
| 81 | 1 | Cover |
| 146 | 1 | Lower plug, upper part |
| 147 | 1 | Balancer |
| 148 □ | 1 | O-ring |
| 150 | 1 | Lower plug, complete (Pos. 146 + 147) |
| 151 □ | 1 | O-ring |

Service kits

| Denomination | DN/OD 51 | DN/OD63.5 | DN/OD 76.1 | DN 80 | DN/OD 101.6 |
|---------------------------|---------------------|--------------------|------------|------------|-----------------------|
| | DN 50 seat ø53.3 | DN65 seat ø81.3 | seat ø81.3 | seat ø81.3 | DN 100 seat ø100.3 |
| Service kits | | | | | |
| □ Service kit, EPDM | 9611928405 | 9611928406 | 9611928406 | 9611928406 | 9611928407 |
| □ Service kit, NBR | 9611928408 | 9611928409 | 9611928409 | 9611928409 | 9611928410 |
| □ Service kit, FPM | 9611928411 | 9611928412 | 9611928412 | 9611928412 | 9611928413 |
| □ Service kit, HNBR | 9611928414 | 9611928415 | 9611928415 | 9611928415 | 9611928416 |

Parts marked with □ are included in the service kit.

NOTE!


If SpiralClean in leakage chamber extra O-rings (2 x pos. 39 and 1 x pos. 40) is required.

All FPM service kits are supplied with EPDM seal ring, pos. 74.

8 Parts list and service kits

For spare parts please refer to spare parts catalogue.

8.6 Plug setup 31



= wear parts

Pos. 37, see section 8.10 Valve bodies

See note below service kits.

8 Parts list and service kits

For spare parts please refer to spare parts catalogue.

Parts list

| Pos. | Qty | Denomination |
|-------|-----|---------------------------------------|
| 15 | 1 | Plug |
| 38 □ | 1 | O-ring |
| 39 | 2 | O-ring |
| 40 | 1 | O-ring |
| 41 | 1 | Flushing tube |
| 42 | 1 | Spindle liner |
| 43 | 2 | Clamp |
| 44 | 1 | Lock |
| 45 | 1 | Guide ring |
| 47 □ | 1 | O-ring |
| 48 | 1 | Upper sealing element |
| 49 □ | 1 | Lip seal |
| 54 | 1 | Guide ring |
| 55 | 1 | Upper plug |
| 56 □ | 1 | Seal ring |
| 57 □ | 1 | Lip seal |
| 58 | 1 | Spray nozzle |
| 74 □ | 2 | Seal ring |
| 76 □ | 1 | O-ring |
| 77 □ | 1 | Lip seal |
| 79 | 1 | Lower sealing element |
| 80 | 1 | Guide ring |
| 81 | 1 | Cover |
| 146 | 1 | Lower plug, upper part |
| 147 | 1 | Balancer |
| 148 □ | 1 | O-ring |
| 150 | 1 | Lower plug, complete (Pos. 146 + 147) |
| 151 □ | 1 | O-ring |

Service kits

| | | DN/OD 51 | DN/OD 63.5 | | | DN/OD 101.6 |
|--------------|-------------------------|------------|------------|------------|------------|-------------|
| | | DN 50 | DN 65 | DN/OD 76.1 | DN 80 | DN 100 |
| Denomination | | seat ø53.3 | seat ø81.3 | seat ø81.3 | seat ø81.3 | seat ø100.3 |
| <hr/> | | | | | | |
| Service kits | | | | | | |
| □ | Service kit, EPDM | 9611928453 | 9611928454 | 9611928454 | 9611928454 | 9611928455 |
| □ | Service kit, NBR | 9611928456 | 9611928457 | 9611928457 | 9611928457 | 9611928458 |
| □ | Service kit, FPM | 9611928354 | 9611928355 | 9611928355 | 9611928355 | 9611928356 |
| □ | Service kit, HNBR | 9611928459 | 9611928460 | 9611928460 | 9611928460 | 9611928461 |

Parts marked with □ are included in the service kit.

NOTE!



If SpiralClean in leakage chamber extra O-rings (2 x pos. 39 and 1 x pos. 40) is required.

All FPM service kits are supplied with EPDM seal ring, pos. 74

8 Parts list and service kits

For spare parts please refer to spare parts catalogue.

8.7 Plug setup 33



○ = wear parts

Pos. 37, see section 8.10 Valve bodies
See note below service kits.

8 Parts list and service kits

For spare parts please refer to spare parts catalogue.

Parts list

| Pos. | Qty | Denomination |
|-------|-----|---------------------------------------|
| 15 | 1 | Plug |
| 38 □ | 1 | O-ring |
| 39 | 2 | O-ring |
| 40 | 1 | O-ring |
| 41 | 1 | Flushing tube |
| 42 | 1 | Spindle liner |
| 43 | 2 | Clamp |
| 44 | 1 | Lock |
| 45 | 1 | Guide ring |
| 47 □ | 1 | O-ring |
| 48 | 1 | Upper sealing element |
| 49 □ | 1 | Lip seal |
| 54 | 1 | Guide ring |
| 55 | 1 | Upper plug |
| 56 □ | 1 | Seal ring |
| 57 □ | 1 | Lip seal |
| 58 | 1 | Spray nozzle |
| 70 | 2 | Flushing tube |
| 71 □ | 2 | O-ring |
| 72 | 1 | Drain |
| 73 | 1 | Nozzle |
| 74 □ | 2 | Seal ring |
| 76 □ | 1 | O-ring |
| 77 □ | 1 | Lip seal |
| 78 □ | 1 | O-ring |
| 79 | 1 | Lower sealing element |
| 80 | 1 | Guide ring |
| 81 | 1 | Cover |
| 146 | 1 | Lower plug, upper part |
| 147 | 1 | Balancer |
| 148 □ | 1 | O-ring |
| 150 | 1 | Lower plug, complete (Pos. 146 + 147) |
| 151 □ | 1 | O-ring |

Service kits

| Denomination | DN/OD 51 | DN/OD 63.5 | DN/OD 76.1 | DN 80 | DN/OD 101.6 |
|---------------------------|------------|------------|------------|------------|-------------|
| | DN 50 | DN 65 | | | DN 100 |
| | seat ø53.3 | seat ø81.3 | seat ø81.3 | seat ø81.3 | seat ø100.3 |
| Service kits | | | | | |
| □ Service kit, EPDM | 9611928369 | 9611928370 | 9611928370 | 9611928370 | 9611928371 |
| □ Service kit, NBR | 9611928372 | 9611928373 | 9611928373 | 9611928373 | 9611928374 |
| □ Service kit, FPM | 9611928375 | 9611928376 | 9611928376 | 9611928376 | 9611928377 |
| □ Service kit, HNBR | 9611928378 | 9611928379 | 9611928379 | 9611928379 | 9611928380 |

Parts marked with □ are included in the service kit.

NOTE!


If SpiralClean in leakage chamber extra O-rings (2 x pos. 39 and 1 x pos. 40) is required.

All FPM service kits are supplied with EPDM seal ring, pos. 74

8 Parts list and service kits


For spare parts please refer to spare parts catalogue.

8.8 Plug setup 37



○ = wear parts

Pos. 37, see section 8.10 Valve bodies
See note below service kits.



8 Parts list and service kits

For spare parts please refer to spare parts catalogue.

Parts list

| Pos. | Qty | Denomination |
|-------|-----|---------------------------------------|
| 15 | 1 | Plug |
| 38 | 1 | O-ring |
| 39 | 2 | O-ring |
| 40 | 1 | O-ring |
| 41 | 1 | Flushing tube |
| 42 | 1 | Spindle liner |
| 43 | 2 | Clamp |
| 44 | 1 | Lock |
| 45 | 1 | Guide ring |
| 46 □ | 1 | O-ring |
| 47 □ | 1 | O-ring |
| 48 | 1 | Upper sealing element |
| 49 □ | 1 | Lip seal |
| 54 | 1 | Guide ring |
| 55 | 1 | Upper plug |
| 56 □ | 1 | Seal ring |
| 57 □ | 1 | Lip seal |
| 58 | 1 | Spray nozzle |
| 66 | 2 | Flushing tube |
| 67 □ | 2 | O-ring |
| 68 | 1 | Drain |
| 69 | 1 | Nozzle |
| 74 □ | 2 | Seal ring |
| 76 □ | 1 | O-ring |
| 95 □ | 1 | Special lip seal |
| 96 | 1 | Lower sealing element, upper part |
| 97 | 1 | Lower sealing element, lower part |
| 98 | 1 | Guide ring, Turcite |
| 146 | 1 | Lower plug, upper part |
| 147 | 1 | Balancer |
| 148 □ | 1 | O-ring |
| 150 | 1 | Lower plug, complete (Pos. 146 + 147) |
| 151 □ | 1 | O-ring, |

Service kits

| Denomination | DN/OD 51 seat ø53.3 | DN 50 seat ø53.3 | DN/OD 63.5 seat ø81.3 | DN 65 seat ø81.3 |
|---------------------------|------------------------|---------------------|--------------------------|---------------------|
| Service kits | | | | |
| □ Service kit, EPDM | 9611928474 | 9611928474 | 9611928475 | 9611928475 |
| □ Service kit, NBR | 9611928477 | 9611928477 | 9611928478 | 9611928478 |
| □ Service kit, FPM | 9611928480 | 9611928480 | 9611928481 | 9611928481 |
| □ Service kit, HNBR | 9611928483 | 9611928483 | 9611928484 | 9611928484 |

Service kits

| Denomination | DN/OD 76.1 seat ø81.3 | DN80 seat ø81.3 | DN/OD 101.6 seat ø100.3 | DN 100 seat ø100.3 |
|---------------------------|--------------------------|--------------------|----------------------------|-----------------------|
| Service kits | | | | |
| □ Service kit, EPDM | 9611928475 | 9611928475 | 9611928476 | 9611928476 |
| □ Service kit, NBR | 9611928478 | 9611928478 | 9611928479 | 9611928479 |
| □ Service kit, FPM | 9611928481 | 9611928481 | 9611928482 | 9611928482 |
| □ Service kit, HNBR | 9611928484 | 9611928484 | 9611928485 | 9611928485 |

Parts marked with □ are included in the service kit.

8 Parts list and service kits

For spare parts please refer to spare parts catalogue.

NOTE!


If SpiralClean in leakage chamber extra O-rings (2 x pos. 39 and 1 x pos. 40) is required.

All FPM service kits are supplied with EPDM seal ring, pos. 74.

8 Parts list and service kits


For spare parts please refer to spare parts catalogue.

8.9 Plug setup 39



○ = wear parts

Pos. 37, see section 8.10 Valve bodies
See note below service kits.



8 Parts list and service kits

For spare parts please refer to spare parts catalogue.

Parts list

| Pos. | Qty | Denomination |
|-------|-----|---------------------------------------|
| 15 | 1 | Plug |
| 38 □ | 1 | O-ring |
| 39 | 2 | O-ring |
| 40 | 1 | O-ring |
| 41 | 1 | Flushing tube |
| 42 | 1 | Spindle liner |
| 43 | 2 | Clamp |
| 44 | 1 | Lock |
| 45 | 1 | Guide ring |
| 47 □ | 1 | O-ring |
| 48 | 1 | Upper sealing element |
| 49 □ | 1 | Lip seal |
| 54 | 1 | Guide ring |
| 55 | 1 | Upper plug |
| 56 □ | 1 | Seal ring |
| 57 □ | 1 | Lip seal |
| 58 | 1 | Spray nozzle |
| 74 □ | 2 | Seal ring |
| 76 □ | 1 | O-ring |
| 95 □ | 1 | Special lip seal |
| 96 | 1 | Lower sealing element, upper part |
| 97 | 1 | Lower sealing element, lower part |
| 98 | 1 | Guide ring, Turcite |
| 146 | 1 | Lower plug, upper part |
| 147 | 1 | Balancer |
| 148 □ | 1 | O-ring |
| 150 | 1 | Lower plug, complete (Pos. 146 + 147) |
| 151 □ | 1 | O-ring |
| | 1 | O-ring |

Service kits

| Denomination | DN/OD 51 seat ø53.3 | DN 50 seat ø53.3 | DN/OD 63.5 seat ø81.3 | DN 65 seat ø81.3 |
|---------------------------|------------------------|---------------------|--------------------------|---------------------|
| Service kits | | | | |
| □ Service kit, EPDM | 9611928498 | 9611928498 | 9611928499 | 9611928499 |
| □ Service kit, NBR | 9611928501 | 9611928501 | 9611928502 | 9611928502 |
| □ Service kit, FPM | 9611928504 | 9611928504 | 9611928505 | 9611928505 |
| □ Service kit, HNBR | 9611928507 | 9611928507 | 9611928508 | 9611928508 |

Service kits

| Denomination | DN/OD 76.1 seat ø81.3 | DN80 seat ø81.3 | DN/OD 101.6 seat ø100.3 | DN 100 seat ø100.3 |
|---------------------------|--------------------------|--------------------|----------------------------|-----------------------|
| Service kits | | | | |
| □ Service kit, EPDM | 9611928499 | 9611928499 | 9611928500 | 9611928500 |
| □ Service kit, NBR | 9611928502 | 9611928502 | 9611928503 | 9611928503 |
| □ Service kit, FPM | 9611928505 | 9611928505 | 9611928506 | 9611928506 |
| □ Service kit, HNBR | 9611928508 | 9611928508 | 9611928509 | 9611928509 |

Parts marked with □ are included in the service kit.

NOTE!

If SpiralClean in leakage chamber extra O-rings (2 x pos. 39 and 1 x pos. 40) is required.

8 Parts list and service kits


For spare parts please refer to spare parts catalogue.

All FPM service kits are supplied with EPDM seal ring, pos. 74.


8 Parts list and service kits

For spare parts please refer to spare parts catalogue.

8.10 Valve bodies



Body combinations - welded bodies



8 Parts list and service kits

For spare parts please refer to spare parts catalogue.


Parts list

| Pos. | Qty | Denomination |
|------|-----|-------------------|
| 37 | 1 | Yoke |
| 50 | 1 | Valve body |
| 60 | 3 | Hexnut |
| 64 | 3 | Clamp without nut |
| 149 | 1 | Valve body |

8 Parts list and service kits

For spare parts please refer to spare parts catalogue.

8.11 Installation kit B



8 Parts list and service kits

For spare parts please refer to spare parts catalogue.


Parts list

| Pos. | Qty | Denomination |
|------|-----|-------------------------|
| 1 | 1 | Hose PTFE w. s.s. weave |
| 2 | 1 | Welding socket |

8 Parts list and service kits

For spare parts please refer to spare parts catalogue.

8.12 Installation kit C



8 Parts list and service kits

For spare parts please refer to spare parts catalogue.


Parts list

| Pos. | Qty | Denomination |
|------|-----|---------------|
| 1 | 1 | Welding liner |
| 2 | 1 | Nut |

8 Parts list and service kits

For spare parts please refer to spare parts catalogue.

8.13 Installation kit G



8 Parts list and service kits

For spare parts please refer to spare parts catalogue.


Parts list

| Pos. | Qty | Denomination |
|------|-----|-----------------------------|
| 1 | 1 | Welding male part, AISI 316 |
| 2 | 2 | 3/8" 10 mm Female PVDF |
| | 1 | 3/8" 10 mm Female PVDF |
| 3 | 1 | 10 mm PVDF hose, 1m |
| | 1 | 10 mm PVDF hose, 1m |

8 Parts list and service kits

For spare parts please refer to spare parts catalogue.

8.14 Installation kit H + B



8 Parts list and service kits

For spare parts please refer to spare parts catalogue.


Parts list

| Pos. | Qty | Denomination |
|------|-----|-------------------------|
| 1 | 1 | DIN union DN10 |
| | 1 | Nut, DN10 |
| | 1 | Welding liner DIN, DN10 |
| | 1 | Packing NBR, DN10 |
| | 1 | Male part DIN, DN10 |
| 2 | 1 | 12 mm CIP pipe long |
| 3 | 1 | 12 mm CIP pipe |
| 4 | 1 | Hose PTFE w. s.s. weave |
| 5 | 1 | Welding socket |

8 Parts list and service kits

For spare parts please refer to spare parts catalogue.

8.15 Axial installation tool



8 Parts list and service kits

For spare parts please refer to spare parts catalogue.


Parts list

| Pos. | Qty | Denomination |
|------|-----|---------------|
| | | Complete tool |
| 1 | 1 | Lower Part |
| 2 | 1 | Piston |
| 3 | 1 | Upper Part |
| 4 | 1 | O-ring, NBR |
| 5 | 1 | Clamp |
| 6 | 1 | Wingnut |
| 7 | 1 | Air fitting |

8 Parts list and service kits

For spare parts please refer to spare parts catalogue.

8.16 Radial installation tool



8 Parts list and service kits

For spare parts please refer to spare parts catalogue.

Parts list

| Pos. | Qty | Denomination |
|------|-----|---------------|
| | | Complete tool |
| 1 | 1 | Piston |
| 2 | 1 | Lower Part |
| 3 | 1 | Upper Part |
| 4 | 1 | Bushing |
| 5 | 1 | Guide |
| 6 | 2 | Guide ring |
| 7 | 1 | O-ring, NBR |
| 8 | 1 | O-ring, NBR |
| 9 | 1 | Clamp |
| 10 | 1 | Wingnut |
| 11 | 1 | Air fitting |

How to contact Alfa Laval

Contact details for all countries are continually updated on our website.

Please visit www.alfalaval.com to access the information directly.

© Alfa Laval Corporate AB

This document and its contents is owned by Alfa Laval Corporate AB and protected by laws governing intellectual property and thereto related rights. It is the responsibility of the user of this document to comply with all applicable intellectual property laws. Without limiting any rights related to this document, no part of this document may be copied, reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), or for any purpose, without the expressed permission of Alfa Laval Corporate AB. Alfa Laval Corporate AB will enforce its rights related to this document to the fullest extent of the law, including the seeking of criminal prosecution.