







- OPTIONS
Support feet and brine connection flanges are considered optionals on request

- BRINE CONNECTION
Brine connection flanges (option) is an adapter vic-flange.
Brine connection position info is necessary only if welded supports are choosen as option. They are placed on top of the unit as per standard.
On request they can be placed alternatively on right side or left side (seen from inlet refrigerant connection side). In this case the complete unit is rotated (not only the shell)

- EQUIPMENT
As per standard, units are delivered with following equipment included:
- Gruvlock and counter-attack brine;
- Refrigerant connections in a separate box

ATTENTION! Informations and dimensions in this document are as a rough guide

	NAME	DATE			
DESIGNER	N. Domenighini	26-03-2013	IF NOT SPECIFIED: DIMENSIONS IN MILLIMETERS	N. DISEGNO PCT277-2-HE	A3
VERIFIED					
APPROVED			REVISION: 00	SCALE:1:15	SHEET 1 OF 1