



- OPTIONS

Support feet and brine connection flanges are considered optionals on request

- BRINE CONNECTION

Brine connection flanges (option) is an adapter vic-flange. Brine connection position info is necessary only if welded supports are chosen as option. They are placed on top of the unit as per standard. On request they can be placed alternatively on right side or left side (seen from inlet refrigerant connection side). In this case the complete unit is rotated (not only the shell)

- EQUIPMENT

As per standard, units are delivered with following equipment included:

- Grivlock and counter-attack brine;
- Refrigerant connections in a separate box

ALFA
LAVAL

ATTENTION! Informations and dimensions in this document are as a rough guide

NAME	DATE	IF NOT SPECIFIED: DIMENSIONS IN MILLIMETERS	N. DISEGNO	A3
DESIGNER N. Domenighini	25-10-2013		PCQ617-3-HE	
VERIFIED				
APPROVED		REVISION: 01	SCALE:1:15	SHEET 1 OF 1