

## **Mounting instructions**

9611-99-5747, Indication unit for LKLA ø133, PNP, Alfa Laval pinout (ZZ0493) Replacing

9612-5108-05, Hall prox. switch unit LKLA ø133, PNP (Grey) 20-30VDC 9612-5108-06, Hall prox. switch unit LKLA ø133, PNP (Green) 5-24VDC


## Items supplied

- 1 x puck E17012
- 1 x inductive double sensor IN5416
- 2 x hexagon head screws
- 2 x socket head screw
- 2 x washers
- 1 x fixing plate

## Wiring (PNP, Alfa Laval pin connection)

Closed: OUT +2 (A2) Pin 3 Open: OUT +1 (A1) Pin 2


Electrical design DC PNP
Operating voltage 10...36 V DC
Output function 2 x NO
Current consumption < 15 mA
Current rating 250 mA
Ambient temperature -25...80 °C
Protection rating IP 67



- ► Loosen the screws (1) and remove the angle bracket.
- Mount the fixing plate, tightening torque 5 Nm ± 1 Nm (2).
- ▶ Mount the puck as shown (3).
- ► Attach the puck and the angle bracket (4).

Pointer showing to the right: Valve is closed. The drawing on the right shows basically an NC (Normally Closed) valve.


Puck pointer must therefore be installed to the right so that it follows the valve closed direction.




► Keep a distance of approx. 2 mm between puck and angle bracket.

Note: Most of the actuators are delivered with a coupling provided with a rim. It ensures the right distance between puck and angle bracket.

- ► Tighten the screws (1).
- ► Tighten opposite grub screws (2) on the puck, tightening torque 2 Nm.



- ► Position sensor as shown. Align the type label properly.
- While doing this, keep the maximum distance between puck and sensor (< 1.5 mm).</p>
- ► Position 1 washer under each screw head (1) and tighten the screws, tightening torque 2 Nm.



Check the feedback for the valve states (open and closed). Indication via LED and visual pointer position.

