

Alfa Laval Cooling insulation

Accessories gasketed plate-and-frame heat exchangers

Introduction

Alfa Laval Cooling insulation is used to thermally insulate gasketed plate-and-frame heat exchangers with operating temperatures between -50°C (-58°F) to 80°C (176°F). The insulation saves energy and reduces condensation and the formation of ice.

Applications

- Biotech and Pharmaceutical
- Chemicals
- Energy and Utilities
- Food and Beverages
- Home and Personal care
- HVAC and Refrigeration
- Machinery and Manufacturing
- Marine and Transportation
- Mining, Minerals and Pigments
- Pulp and Paper
- Semiconductor and Electronics
- Water and Waste treatment

Benefits

- Saves energy
- Prevents condensation and formation of ice
- Easy to install

Design

Alfa Lava Cooling insulation is available for some of the heat exchangers in the Industrial line and the Industrial semi-welded line. The cooling insulation sections (panels) are designed to ensure simple assembly and disassembly. The panels are equipped with connecting spring locks in galvanized steel.

Selection

To be able to make a quotation, please specify:

- Frame type
- A-measurement
- Type of connections
- Connection positions



Technical data

Cladding	Aluminium stucco sheet 1.0 mm (0.039in)
Insulation	Polyurethane 40kg/m ³ , 60 mm (2.36 in)
Inside layer	Aluminium foil 0.05 mm (0.002 in)
Panel fixation	Snap locks

Approximate dimension

The table shows maximum dimensions and might be smaller. For exact measurements please use the sales configurator tool. Measurements in mm (inch).


	00		J,.		
Product	L 1	W	H ²	W_1	L ₁
M6-FM, ³ M6-	A + 350	460	1042	480	B + 166
FG ³⁾	(13.78)	(18.11)	(41.02)	(18.90)	(6.53)
TL6-FM, ³⁾	A . 000	400	1.400	400	D . 100
TL6-FG,3)	A + 380	480	1432	480	B + 166
TL6-FD 3)	(14.96)	(18.90)	(56.38)	(18.90)	(6.53)
M10-FM, ³⁾					
M10-FG, ³⁾	A + 475	600	1202	700	B + 290
M10-FD, ³⁾	(18.70)	(23.62)	(47.32)	(27.56)	(11.41)
M10-FT 3)					
M40 EV 3)	A + 595	600	1257	700	B + 150
M10-FX ³⁾	(23.42)	(23.62)	(49.49)	(27.56)	(5.90)
M10-REF ³⁾	A + 350	600	1120	630	B + 150
	(13.78)	(23.62)	(44.09)	(24.80)	(5.90)
TL10-FM,	A + 380	610	2072	700	A + 740
ILIU-FIVI,	(14.96)	(24.01)	(81.57)	(27.56)	(29.13)
TL10-FG,	A + 410	610	2112	700	A + 740
TL10-FD	(16.14)	(24.01)	(83.15)	(27.56)	(29.13)
TL10-FS	A + 450	640	2112	730	A + 740
	(17.72)	(25.20)	(83.15)	(28.74)	(29.13)
M15-FM	A + 360	740	2062	770	A + 660
	(14.17)	(29.13)	(81.18)	(30.31)	(25.98)
M15-FG	A + 440	800	2062	820	A + 740
	(17.32)	(31.50)	(81.18)	(32.28)	(29.13)
M15- FD	A + 500	820	2162	850	A + 800
	(19.68)	(32.28)	(85.12)	(33.46)	(31.50)
MK15-FG,					
MK15-FD,	A + 600	810	1607	840	A + 725
MK15-FT,	(23.62)	(31.89)	(63.27)	(33.07)	(28.54)
MK15-FGR,	(====)	(=)	(===:)	(00.0.)	(==:=:,)
MK15-FDR					
TL15-FM	A + 350	760	2872	800	A + 650
	(13.78)	(29.92)	(113.07)	(31.50)	(25.59)
TL15-FG,	A + 530	820	2872	840	A + 830
TL15-FD,	(20.87)	(32.28)	(113.07)	(33.07)	(32.68)
TL15-FS					
T20-FG	A + 480	910	2287	950	A 750
	(18.90)	(35.83)	(90.04)	(37.40)	(29.53)
T20-FD, T20-	A + 530	930	2332	970	A 750
FS	(20.87)	(38.19)	(91.81)	(38.19)	(29.53)
TK20-FG	A + 495	870	1642	910	A + 615
	(19.49)	(34.25)	(64.64)	(35.83)	(24.21)
4					

 $^{^{1}}$ L = A + total insulation measure.

TK20-FD	A + 525	915	1642	955	A + 645
	(20.67)	(36.02)	(64.64)	(37.60)	(25.39)
TK20-FX	A + 610	915	1677	955	A + 730
	(24.01)	(36.02)	(66.02)	(37.60)	(28.74)
MX25-FG, MX25-FD, MX25-FS	A + 580 (22.83)	1060 (41.73)	3202 (126.06)	1100 (43.31)	A + 880 (34.64)
MX25-FMS,	A + 490	1060	2722	1090	A + 790
MX25-FGS	(19.29)	(41.73)	(107.16)	(42.91)	(31.10)
T25-FG	A + 510	1060	2783	1110	LC + 435
	(20.08)	(41.73)	(109.57)	(43.70)	(17.13)
T25-FD	A + 590	1080	2837	1130	LC + 475
	(23.23)	(42.52)	(111.69)	(44.49)	(18.70)
T25-FS	A + 630	1080	2837	1130	LC + 490
	(24.80)	(42.52)	(111.69)	(44.49)	(19.29)
TL35-FM	A + 550	1310	3252	1350	A + 850
	(21.65)	(51.57)	(128.03)	(53.15)	(33.46)
TL35-FG	A + 605	1310	3332	1350	A + 905
	(23.82)	(51.57)	(131.18)	(53.15)	(35.63)
TL35-FD,	A + 700	1320	3342	1360	A + 1000
TL35-FS	(7.56)	(51.97)	(131.57)	(53.54)	(37.37)

 $^{^{1}}$ L = A + total insulation measure.

 $^{^3\} L = Ltot$ (the complete heat exchanger inside the insulation)



For actual heat exchanger measurements see PHE drawing

A =	= F	Plate	pack	length

B = Foot print length

C = Total length

LC = Length of carrying bar

Ltot = C + 0.5 insulation measure

D = Drainage

This document and its contents is owned by Alfa Laval Corporate AB and protected by laws governing intellectual property and thereto related rights. It is the responsibility of the user of this document to comply with all applicable intellectual property laws. Without limiting any rights related to this document, no part of this document may be copied, reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), or for any purpose, without the expressed permission or authorized by Alfa Laval Corporate AB. Alfa Laval Corporate AB will enforce its rights related to this document to the fullest extent of the law, including the seeking of criminal prosecution.

200000037-2-EN-GB © Alfa Laval Corporate AB

 $^{^2}$ The height (H) includes the thickness of the drip tray which is placed under the heat exchanger. NOTE! The vertical positions of the connections are 62 mm (2.44 inch) higher for installations that include a drip tray.

³ L = Ltot (the complete heat exchanger inside the insulation)

 $^{^2}$ The height (H) includes the thickness of the drip tray which is placed under the heat exchanger. NOTE! The vertical positions of the connections are 62 mm (2.44 inch) higher for installations that include a drip tray.